

RUGGEDCOM WIN7200

Installation Guide

Preface

FCC Statement And Cautions

Introduction

1

Product Description

2

Site and Installation Requirements

3

Installation Procedures

4

Setup

5

Troubleshooting

6

List of Acronyms

A

WIN7200 Specifications

B

IDU to ODU Cable Specifications

C

Console Connector Specifications

D

WIN7200 Base Station Mechanical Drawing

E

Table of Contents

Preface	vii
Alerts	vii
Related Documents	vii
Accessing Documentation	viii
Training	viii
Customer Support	viii
FCC Statement And Cautions	ix
Chapter 1	
Introduction	1
1.1 Safety Information	1
1.1.1 General	1
1.1.2 Equipment Installation	1
1.1.3 Radio Frequency (RF) Exposure	1
1.1.4 Lightning Protection	2
1.1.5 Power Cord Protection	2
1.1.6 Servicing	2
1.1.7 Antenna Grounding Requirements	3
1.1.8 Outdoor Grounding System	3
1.1.9 Safety Hazards	3
1.2 Allowed Antenna Types	3
Chapter 2	
Product Description	5
2.1 About the RUGGEDCOMWIN7200	5
2.2 Capabilities and Features	6
2.3 System Architecture	6
2.4 Interfaces	7
2.4.1 Bottom Panel	7
2.4.2 Top Panel	8
Chapter 3	
Site and Installation Requirements	9
3.1 WIN7200 Installation Location	9
3.1.1 Criteria for Outdoor Locations	9

3.1.2	Criteria for Indoor Locations	9
3.1.3	External GPS Antenna Installation Location	9
3.1.4	Antenna Grounding Requirements	10
Chapter 4		
	Installation Procedures	11
4.1	Pre-Installation Safety Instructions	11
4.2	Package Components and Unpacking	11
4.3	Cat5 Cable Requirements	11
4.4	Required Tools and Materials	12
4.5	Installing the Base Station	12
4.5.1	Cover the Console Port	13
4.5.2	Assembling the PoE Connector	13
4.5.3	Attaching the Mounting Bracket	17
4.5.4	Mounting the Base Station: Wall Mount	18
4.5.5	Mounting the Base Station: Pole Mount	19
4.5.6	Antenna Connections	21
4.5.6.1	RF Connections and Grounding	21
4.5.6.2	Optional External GPS Antenna Connections	21
4.5.7	Connecting the Base Station Data Adaptor	22
4.5.8	Weatherproofing	23
4.5.8.1	Weatherproofing Cable Connections	23
4.6	Hazardous Location Installation	26
Chapter 5		
	Setup	29
5.1	Connecting to the WIN7200 Web Interface	29
Chapter 6		
	Troubleshooting	33
6.1	No IP Connectivity	33
6.2	No Serial Connection	33

Appendix A
List of Acronyms 35

Appendix B
WIN7200 Specifications 37

Appendix C
IDU to ODU Cable Specifications 41

Appendix D
Console Connector Specifications 43

Appendix E
WIN7200 Base Station Mechanical Drawing 45

Preface

This guide describes the RUGGEDCOM WIN7200 high power base station. It describes the major features of the base station, installation, commissioning and important technical specifications.

It is intended for use by network technical support personnel who are responsible for the installation, commissioning and maintenance of the base station. It is also recommended for use by network and system planners, system programmers, and line technicians.

**IMPORTANT!**

While this guide does address some safety precautions, it is assumed that installation personnel are trained in safe installation practices. Personnel unfamiliar with safe installation procedures, WiMAX technologies, or service procedures should not rely on this guide for comprehensive guidance.

Alerts

The following types of alerts are used when necessary to highlight important information.

**DANGER!**

DANGER alerts describe imminently hazardous situations that, if not avoided, will result in death or serious injury.

**WARNING!**

WARNING alerts describe hazardous situations that, if not avoided, may result in serious injury and/or equipment damage.

**CAUTION!**

CAUTION alerts describe hazardous situations that, if not avoided, may result in equipment damage.

**IMPORTANT!**

IMPORTANT alerts provide important information that should be known before performing a procedure or step, or using a feature.

**NOTE**

NOTE alerts provide additional information, such as facts, tips and details.

Related Documents

Other documents that may be of interest include:

- *RUGGEDCOM WIN1210 Installation Guide*
- *RUGGEDCOM WIN1212 Installation Guide*

- *RUGGEDCOM BST Web Manager User Guide*

Accessing Documentation

The latest Hardware Installation Guides and Software User Guides for most RUGGEDCOM products are available online at www.siemens.com/ruggedcom.

For any questions about the documentation or for assistance finding a specific document, contact a Siemens sales representative.

Training

Siemens offers a wide range of educational services ranging from in-house training of standard courses on networking, Ethernet switches and routers, to on-site customized courses tailored to the customer's needs, experience and application.

Siemens' Educational Services team thrives on providing our customers with the essential practical skills to make sure users have the right knowledge and expertise to understand the various technologies associated with critical communications network infrastructure technologies.

Siemens' unique mix of IT/Telecommunications expertise combined with domain knowledge in the utility, transportation and industrial markets, allows Siemens to provide training specific to the customer's application.

For more information about training services and course availability, visit www.siemens.com/ruggedcom or contact a Siemens sales representative.

Customer Support

Customer support is available 24 hours, 7 days a week for all Siemens customers. For technical support or general information, contact Siemens Customer Support through any of the following methods:

- **Online**

Visit <http://www.siemens.com/automation/support-request> to submit a Support Request (SR) or check on the status of an existing SR.

- **Telephone**

Call a local hotline center to submit a Support Request (SR). To locate a local hotline center, visit <http://www.automation.siemens.com/mcms/aspa-db/en/automation-technology/Pages/default.aspx>.

- **Mobile App**

Install the Industry Online Support app by Siemens AG on any Android, Apple iOS or Windows mobile device and be able to:

- Access Siemens' extensive library of support documentation, including FAQs, manuals, and much more
- Submit SRs or check on the status of an existing SR
- Find and contact a local contact person
- Ask questions or share knowledge with fellow Siemens customers and the support community
- And much more...

FCC Statement And Cautions

Federal Communications Commission Radio Frequency Interference Statement

This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.



CAUTION!

Caution: Service

This product contains no user-serviceable parts. Attempted service by unauthorized personnel shall render all warranties null and void.

Changes or modifications not expressly approved by Siemens Canada Ltd. could invalidate specifications, test results, and agency approvals, and void the user's authority to operate the equipment.



CAUTION!

Caution: Physical Access

This product should be installed in a restricted access location where access can only be gained by service personnel or users who have been instructed about the reasons for the restrictions applied to the location and about any precautions that shall be taken; and access is through the use of a tool or lock and key, or other means of security, and is controlled by the authority responsible for the location.



Introduction

This user guide provides essential product functionality with all the information necessary to professionally install and configure the RUGGEDCOM WIN7200 Small Form Factor Base Station.

This guide is intended for experienced technicians and operators. It is assumed that the customers installing, operating and maintaining this product are familiar with WiMAX technologies and procedures.

While some safety precautions are reviewed here, this manual assumes that installers have been trained in safe installation practices. Users who are new to WiMAX technologies and service procedures should not rely on this manual for comprehensive guidance.

Section 1.1

Safety Information

Safety information is provided in the following sections.

Section 1.1.1

General

- Read this User Manual and follow all operating and safety instructions.
- The base station and antenna must be installed by a professional installer.
- The power requirements are indicated on the product-marking label. Do not exceed the described limits.

Section 1.1.2

Equipment Installation

The equipment should be installed in accordance with the National Electrical Code (NEC), ANSI/NFPA 70, the Canadian Electrical Code (CEC), Part 1, CSA C22.1; and when applicable, the National Electrical Safety Code IEEE C2. Unless marked or otherwise identified, the Standard for the Protection of Electronic Computer/Data Processing Equipment, ANSI/NFPA 75, also applies.

Section 1.1.3

Radio Frequency (RF) Exposure

The WIN7200 is compliant with the requirements set forth in CFR 47 section 1.1307, addressing Radio Frequency (RF) exposure from radio frequency devices as defined in OET Bulletin 65. The outdoor base station should be positioned more than 0.6 feet (20 cm) from humans.



WARNING!

For WIN7249 and WIN7258, keep distance of more than 38 cm (15 in) from humans. All other models must be positioned 20 cm (8 in) from humans.

Section 1.1.4

Lightning Protection



WARNING!

When the WIN7200 unit is installed in an outdoor location, all indoor components (Ethernet, power supply) should be connected through a lightning protector.

Lightning protection protects people and equipment located indoors from lightning that might strike the WIN7200 unit or its outdoor cables. Therefore, the lightning protector device should be installed indoors, as close as possible to the point where the cables enter the building. The lightning protector can also be installed outdoors, as long as the cables that go from it indoors are well protected from lightning between the box and the building entrance.

Section 1.1.5

Power Cord Protection

The RUGGEDCOM WIN7200 should always be connected to the supplied data adaptor for both power supply and data transfer purposes.

Any other type of connection/application of the WIN7200 and/or supplied data adaptor is not allowed.

Route all power supply cords so that people cannot walk on them or place objects on or against them. This can pinch or damage the cords.

Section 1.1.6

Servicing

Do not open the cover of this product and attempt service unless instructed by a RUGGEDCOM certified technician. Refer all repairs to qualified service personnel. Removing the covers or modifying any part of this device voids its warranty. Siemens does not endorse or support the use of proprietary third-party outdoor cable assemblies not supplied by Siemens.



WARNING!

Keep away from electric power lines.

Carefully read and follow all instructions in this manual. By nature of the installation, you may be exposed to hazardous environments and high voltage. Use caution when installing the outdoor system.

Section 1.1.7

Antenna Grounding Requirements

Verify that the antenna or cable system is grounded (earthed).

The antenna installation must be as per Article 810 of the NEC. Of particular note is the requirement that the grounding conductor not be less than 10 AWG (Cu). The scheme should be either in accordance with UL 96 and 96A. Lightning Protection Components and Installation Requirements for Lightning Protection Systems, or tested in accordance with UL 50 and UL 497.

Section 1.1.8

Outdoor Grounding System



WARNING!

Verify that the base station is grounded.

The system must be properly grounded to protect against power surges and accumulated static electricity. It is the installer's responsibility to install this device in accordance with the local electrical codes.

Section 1.1.9

Safety Hazards



WARNING!

- *Installing the WIN7200 can pose a serious hazard. Be sure to take precautions to avoid the following:*
- *Exposure to high voltage lines during installation*
- *Falling when working at heights or with ladders*
- *Injuries from dropping tools*
- *Contact with AC wiring (power system connection)*



WARNING!

To reduce the risk of fire, only use a No. 24AWG or larger telecommunication line cord between the indoor and outdoor units.

Section 1.2

Allowed Antenna Types



IMPORTANT!

For the WIN7258 only, in accordance with with Act 1135, regulation 506, section 9, published by ANATEL (Agência Nacional de Telecomunicações), maximum combined peak power of both antenna outputs is 29 dBm.



NOTE

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

This radio transmitter (WIN7249, WIN7258) has been approved by Industry Canada to operate with the antenna types listed below with the maximum permissible gain and required antenna impedance for each antenna type indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

Le présent émetteur radio (WIN7249, WIN7258) a été approuvé par Industrie Canada pour fonctionner avec les types d'antenne énumérés ci-dessous et ayant un gain admissible maximal et l'impédance requise pour chaque type d'antenne. Les types d'antenne non inclus dans cette liste, ou dont le gain est supérieur au gain maximal indiqué, sont strictement interdits pour l'exploitation de l'émetteur.

The following table contains a list of approved 4.9/5.8Ghz antenna types for the following models: WIN7249 and WIN7258.

Table: Antenna Types

Type	Manufacturer	Model Number	Gain	Impedance
Sector dual slant antenna	MTI Wireless Edge Ltd.	MT – 464018/ND	16 dBi	50Ω
Omnidirectional	MTI Wireless Edge Ltd.	MT-462008/N/A	9.5 dBi	50Ω



NOTE

Under Industry Canada regulations, for WIN7258, reduce the maximum output power to 20 dBm when using a 16 dBi antenna.

2 Product Description

Section 2.1

About the RUGGEDCOM WIN7200

The WIN7200 Small Form Factor Base Station is a member of the RUGGEDCOM family, a line of mobile WiMAX broadband wireless access systems based on the 802.16e mobile WiMAX standard. RUGGEDCOM systems are designed for robustness and simplicity, offering feature-rich services with low deployment and operation costs, for unmatched operator competitiveness and fast return on investment.

The WIN7200 is a single sector station that enhances outdoor and indoor WiMAX coverage and capacity. The unit is easily installable by one person, is powered by Power over Ethernet (PoE), and supports remote management. The WIN7200 is supported by Siemens's RUGGEDCOM NMS software.

Available in 2.XGHz and 3.XGHz frequency ranges, the WIN7200 provides full base station functionality for serving a single sector. The WIN7200 communicates with fixed and mobile subscriber units according to defined service criteria and customer Service Level Agreements (SLA). The WIN7200 also supports end-to-end Quality of Service (QoS) requirements.

The WIN7200 features a small footprint and flexible mounting options, allowing it to be easily mounted by one person on poles, street lamps, or walls.



Figure 1: WIN7200



NOTE

This device complies with Industry Canada license-exempt RSS standard. Operation is subject to the following two conditions:

- *this device may not cause interference, and*
- *this device must accept any interference, including interference that may cause undesired operation of the device.*

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- *l'appareil ne doit pas produire de brouillage, et*
- *l'utilisateur de l'appareil doit accepter tout brouillage radio électrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.*

Section 2.2

Capabilities and Features

- Supported Frequency Bands: 5251, 5151, 7251
- All-outdoor, one-box base station solution
- GPS synchronization
- MIMO (2×2) support
- Non-Line-of-Sight (NLOS)
- Small footprint and light weight enables simple installation and deployment by a single person
- IEEE802.16e Wave2 Standard Compliance
- Backbone Ethernet connectivity via a 10/100 Base-T network interface
- Fixed and mobile CPE support
- 3.5 MHz, 5MHz, 7MHz and 10MHz channel bandwidth support
- Different RF options including 2.x, 3.x, 4.9 GHz, and 5.8 GHz band support
- Traffic classification and connection establishment initiation
- Policy-based data switching
- Quality of Service (QoS) management
- Alarms management
- An SNMP agent incorporated into the unit enables extensive In-Band (IB) management of the base station and all its registered CPEs
- An R6 interface to ASN-GW profile C

Section 2.3

System Architecture

The WIN7200 unit receives power and data over PoE.




Figure 2: Power Over Ethernet Block Diagram

Section 2.4

Interfaces

Install the unit vertically, with the integrated GPS antenna located on the top panel (facing the sky). All other connections, including the optional GPS external antenna connections are located on the bottom panel.

Section 2.4.1

Bottom Panel

The interface panel supports the antenna, power and Ethernet connections.



Figure 3: WIN7200 Interface Panel

The following table provides a description of the base station bottom panel connectors and ports.

Table: WIN7200 Interface Connectors

Connector Name	Connector Type	Cable Type	Function	Connected to
ANT1	N typeFemale	RG 214/U	RF antenna connection	External antenna or screwed-on omni-directional antenna
CONSOLE	RJ45	Cat5 ETH	Low level CLI for technical personnel. RS-232	Computer
DC/ETH	RJ45	Cat5 ETH	DC 1.5A + Ethernet Cat5	PoE data adaptor
GND	1 screwETSI	#10 AWG bare copper wire	Grounding lug. #10 AWG bare copper wire	Central earth ground, tower or pole chassis
GPS (optional)	TNCFemale	LMR200	Base Station Synchronization	External GPS antenna
ANT2	N typeFemale	RG 214/U	RF antenna connection	External antenna or screwed-on omni-directional antenna

Section 2.4.2

Top Panel

The top panel supports the built-in GPS antenna. (An external GPS antenna can be connected to the bottom panel GPS connector). See [Section 3.1.3, “External GPS Antenna Installation Location”](#) for more information on GPS antennae and installation criteria.

The figure below shows the base station mounted on a pole.




Figure 4: WIN7200 Top Panel GPS Antenna

3

Site and Installation Requirements

Section 3.1

WIN7200 Installation Location



WARNING!

The WIN7200 unit must always be installed vertically and top-down – with the connectors on the underside for protection.

This section describes the criteria that should be considered when selecting the WIN7200 installation location.

Section 3.1.1

Criteria for Outdoor Locations

Take into account your site plan and local regulations that define distance from populated areas. Follow these guidelines:

- The unit should be mounted at the highest possible point. Reception will increase according to the height of the antennae.
- There should be few obstacles between the antenna and the planned coverage area (zone) – minimum of 55% exposure to the sky.
- Take into account (according to your coverage site plan) the distance from other antennae or devices that may cause interferences.
- The unit should be accessible for maintenance (where possible).

Section 3.1.2

Criteria for Indoor Locations

- A minimum of 55% direct Line-of-Sight (LOS) exposure of the external GPS antenna to sky.
- The maximum distance from the external GPS antenna to the WIN7200 should be 22 meters.

Section 3.1.3

External GPS Antenna Installation Location

The following criteria should be considered when selecting the GPS antenna installation site location to determine the optimal position for the antenna:

- Antenna visibility - The GPS antenna should be mounted in a position where at least 55% of the antenna area is exposed to the sky.

- The distance from the GPS antenna to the base station should not exceed the maximum distance of 22 meters. Otherwise, the length of the GPS antenna cable will cause interferences.

Section 3.1.4

Antenna Grounding Requirements

The antenna installation must be as per Article 810 of the NEC. Of particular note is the requirement that the grounding conductor be not less than 10 AWG (Cu). The scheme should either correspond to UL 96 and 96A. Lightning Protection Components and Installation Requirements for Lightning Protection Systems, or tested in accordance to UL 50 and UL 497.

4

Installation Procedures

Section 4.1

Pre-Installation Safety Instructions



WARNING!

Before installing the base station, review the following safety hazards:

- *Installing the base station can pose a serious hazard. Be sure to take precautions to avoid the following:*
- *Exposure to high voltage lines during installation*
- *Falling when working at heights or with ladders*
- *Injuries from dropping tools*
- *Contact with AC wiring (power system connection)*

Section 4.2

Package Components and Unpacking

Upon receiving the unit, perform the following:

Procedure: Unpacking the Base Station

1. Examine the shipping container for damage before unpacking the unit.
2. Perform a visual inspection to reveal any physical damage to the equipment.
3. Verify that all of the equipment (listed below) is included. Otherwise contact Siemens.

The base station is shipped with the following equipment:

- The base station unit.
- GPS antenna
- AC power supply
- 2×RF cables 1.6 m for connection to antenna
- Pole / wall mount kit


Section 4.3

Cat5 Cable Requirements

All Cat5 cables used in the installation of the base station must meet the following requirements:

- Must be provided or approved by Siemens
- Must not be longer than 80 m (262 ft)

- Must be ground as shown in [Figure 5](#)



Section 4.4

Required Tools and Materials

To install the base station, a standard professional toolbox is required.

When wall-mounting the base station, use wall anchors (not supplied) suitable for the wall material.

Section 4.5

Installing the Base Station



NOTE

The unit should be installed at the highest possible point!



WARNING!

The equipment should be installed in compliance with the National Electrical Code (NEC), ANSI/NFPA 70, the Canadian Electrical Code (CEC), Part 1, CSA C22.1; and when applicable, the National Electrical Safety Code IEEE C2. Unless marked or otherwise identified, the Standard for the Protection of Electronic Computer/Data Processing Equipment, ANSI/NFPA 75.

There are two types of installations:

- **Wall mount:** The base station can be attached to any wall that can support the load of the unit.
- **Pole mount:** The base station can be attached to any pipe or pole with a diameter of 1.75" to 10".

To install the base station, follow these steps:

1. Cover the Console port (only used for maintenance purposes by authorized personnel). See [Section 4.5.1, “Cover the Console Port”](#).
2. Assemble the PoE connector. See [Section 4.5.2, “Assembling the PoE Connector”](#).
3. Assemble the base station mounting bracket. See [Section 4.5.3, “Attaching the Mounting Bracket”](#).
4. Mount the base station to a wall or pole. See [Section 4.5.4, “Mounting the Base Station: Wall Mount”](#) and [Section 4.5.5, “Mounting the Base Station: Pole Mount”](#).
5. Complete the antenna connections and grounding. See [Section 4.5.6, “Antenna Connections”](#).
6. Connect the base station Data Adaptor. See [Section 4.5.7, “Connecting the Base Station Data Adaptor”](#).
7. Perform the initial base station setup. See [Chapter 5, Setup](#).

Section 4.5.1

Cover the Console Port

The Console port is only used for maintenance operations performed by authorized service personnel. It should be closed with the attached cover in normal conditions.

**NOTE**

See [Appendix D, Console Connector Specifications](#) for information on the console cable pinout.

Section 4.5.2

Assembling the PoE Connector

A custom PoE cable with a special RJ45 connector is required to connect a PoE injector to the DC/ETH port. The following materials and tools are required:

- The RJ45 connector kit (included). Contains an RJ45 connector and loading bar.
- CAT-5e cable of suitable length for your application. For information on cable specifications, refer to [Appendix C, IDU to ODU Cable Specifications](#).
- Standard cable splicing tools, including a standard crimp tool.

To assemble the PoE connector, do the following:

1. Slide the connector components on to the wire.




Figure 6: Assembling the Connector Components

1. Plug Housing 2. Dust Cover

2. Strip the wire jacket 38 mm (1.5 in) from the tip, making sure not to cut the foil or drain wire.




Figure 7: Cutting the Jacket

1. Wire Jacket 2. Foil

3. Fold the foil back over the wire jacket.




Figure 8: Folding Back the Foil

1. Foil 2. Twisted-Pair Wires 3. Drain Wire

4. Bend the drain wire back over the jacket.




Figure 9: Bending the Drain Wire
1. Foil 2. Drain Wire 3. Twisted-Pair Wires

5. Partially untwist each wire pair, making sure to retain a half twist at the end.




Figure 10: Untwisting the Wire Pairs

6. Arrange the wires according to the following pin-out description:




Figure 11: CAT-5e PoE Cable Pin-Out
1. Pin 1 2. Pin 8

Pin Number	Color	Description	
1	White/Orange	ETH Data	TP0+
2	Orange	ETH Data	TP0-
3	White/Green	ETH Data	TP1+
4	Blue	55 V	TP2+
5	White/Blue	55 V	TP2-
6	Green	ETH Data	TP1-
7	White/Brown	RTN (-)	TP3+
8	Brown	RTN (-)	TP3-

7. Slide the wires into the loading bar and then pull the loading bar down until its face is 16 mm (0.63 in) from the wire jacket. If necessary, use pliers to hold the wires while pulling the loading bar.




Figure 12:

1. Loading Bar 2. Wires 3. Pin 1 4. Pin 8

8. Trim the wires until they are flush with the face of the loading bar.
9. Insert the wires and loading bar into the plug body. Make sure:
 - the cable is pushed to the front of the plug body
 - the spine of the strain relief on the plug body covers the drain wire
10. Bend the strain relief until it is flat against the jacket and foil.
11. Crimp the plug and strain relief using a standard crimping tool.
12. Trim away any excess foil or drain wire extruding from the strain relief.
13. Slide the connector components up to the plug body.
14. Insert the modular plug into the plug housing.




Figure 13: Assembling the Connector Components

1. PoE Plug 2. Plug Housing 3. Dust Cover

15. Align the latch with the LATCH slot.
16. Press the plug into the plug housing until it bottoms out.
17. While maintaining inward pressure on the plug or keeping the dust cover engaged, tighten the compression nut to 0.56 N·m (5 In-lbs).

Section 4.5.3

Attaching the Mounting Bracket

Follow these steps to attach the mounting bracket to the base station.




Figure 14: Wall Mounting Bracket

Procedure: Assembling the Base Station and Mounting Bracket

1. Align the mounting bracket's four inner holes with the base station's installation holes, located on the ribbed side of the unit.




Figure 15: Attaching the Mounting Bracket

2. Secure the bracket to the base station unit with the four screws and washers (supplied).

Section 4.5.4

Mounting the Base Station: Wall Mount

The base station can be attached to any wall that can support the load of the unit.



NOTE

Plan the installation so that the interface connections face down, providing more protection against the elements.

Follow these step to mount the base station on a wall.

Procedure: Wall-mounting the Base Station

1. Determine the location of the base station mounting bracket. Mark the mounting holes on the wall surface based on the bracket's four outer mounting holes, two at the top and two at the bottom.




Figure 16: Base Station and Wall Mounting Bracket: Rear View

2. Drill four holes in the wall. If required, insert wall anchors (not supplied) in the wall. Align the bracket installation holes with the holes in the wall. Secure with the appropriate screws and washers (not supplied).

Section 4.5.5

Mounting the Base Station: Pole Mount

The unit can be attached to any pipe or pole with a 1.75" to 10" diameter.



NOTE

Plan the installation so that the interface connections face down, providing more protection against the elements.

Follow these steps to mount the base station on a pole.

Procedure: Pole-mounting the Base Station

1. Assemble the wall-mounting bracket to the ribbed side of the unit.
2. Insert the metal bands in the bracket slots, as shown below.




Figure 17: Base Station and Pole Mounting Bracket

3. Mount the unit on the pole, using the metal bands. Close the bands tightly around the pole.




Figure 18: Base Station Pole Mounting: Rear View

Section 4.5.6

Antenna Connections



WARNING!

The part of the antenna that is connected to the central pin of the antenna connector should be covered by isolation material which is sufficiently resistant to degradation by ultraviolet (UV) radiation.

Section 4.5.6.1

RF Connections and Grounding



NOTE

See [Section 1.1.7, "Antenna Grounding Requirements"](#) for antenna grounding requirements.

Connect the antennae to the N-Type ANT1 and ANT2 connectors and connect the grounding lug to the common ground.

Section 4.5.6.2

Optional External GPS Antenna Connections

Remove the cover from the GPS port and connect the external GPS antenna to the port. Refer to the following specifications for the external GPS antenna:

- Cable Type: LMR200

- Cable connectors: TNC
- Cable length: 15m

Section 4.5.7

Connecting the Base Station Data Adaptor

The Data Adaptor is a combined data and power adaptor that interfaces with the customer's Outdoor Unit wireless device. It is used to power the base station and to distribute data.

The Data Adaptor unit includes a single output RJ-45 connector (for connection to an IEEE802.3 compatible device) that provides bi-directional 10/100 Base-T data and power to the outdoor equipment over a Cat5e cable.

The unit receives power from 100V to 240V AC using an IEC-320-C14 industry standard connector.

For information on the connector pinout, see [Section 4.5.2, "Assembling the PoE Connector"](#).



NOTE

The AC power supply cord should be 3 wires, 18 AWG minimum, with a length of less than 4.5 m, and safety certified according to national rules.

Follow these steps to connect the base station Data Adaptor.

Procedure: Connecting the Base Station Data Adaptor

1. Connect the base station CD/ETH port to the Data Adaptor ODU IF port using the cable you assembled earlier. For instructions on assembling the PoE cable, see [Section 4.5.2, "Assembling the PoE Connector"](#).



NOTE

The maximum length of the indoor-to-outdoor CAT5 cable should not exceed 80m.

The Cat5e Ethernet cable is not included. Refer to [Appendix C, IDU to ODU Cable Specifications](#) for detailed technical specifications.

2. Connect the Data Adaptor to a Switch/Router by connecting the Data Adaptor's Ethernet port and the Switch/Router 10/100 Base T-port using a Cat5e cable.
3. Connect the Data Adaptor to the 110V/220V AC mains using the supplied cable.



WARNING!

Before connecting the data adaptor to the main outlet, verify that all system components are properly installed. Make sure that all cable connectors are securely positioned in the appropriate ports.

4. Verify that the Data Adaptor LEDs located on the front panel are Green, indicating an OK status.

Table: Data Adaptor LED Indicators

LED	Color	Description
PWR	Green	Input power is connected
LAN	Green	LAN link/activity display

Section 4.5.8

Weatherproofing

It is extremely important to weatherproof all outdoor cable connections. Weatherproofing the connections at the outdoor unit and antennas prevents corrosion, prevents water from interfering with the connection, and helps to keep the connection tight. Because cables also carry DC current, the need for proper weatherproofing cannot be overstated.

We recommend the use of sealing tapes designed for outdoor use:

- 3M™ Scotch® Super 88 Electrical Tape
- Heavy-duty weather-, abrasion-, and UV-resistant rubber splicing tape or self-amalgamating tape

Rubber mastic putty or duct sealing putty must also be used to complete the weatherproofing where needed. We do not recommend silicon seal or glue. These materials are difficult to apply accurately and are difficult to remove. Do not use PVC tape.

Section 4.5.8.1

Weatherproofing Cable Connections

Most outdoor unit, antenna, or cable problems are caused by coaxial cable connections loosened by vibration, allowing moisture to penetrate the connector interface. We recommend that all outdoor unit-to-cable connections be weatherproofed using a procedure similar to the one described below.

This method of weatherproofing must be completed on *all* external connections. If surge arrestors are used, all the associated connections and arrestors must be completely wrapped with splicing tape or self-amalgamating tape.

**NOTE**

Before waterproofing, ensure all connectors are correctly tightened. Ensure the connector and cables are free of foreign substances such as oil, water, grease, and dirt. Ensure that the cable extends below the connector to which it is attached, providing a path for water to follow away from the connected device.

Procedure: Weatherproofing Cable Connectors

1. Begin to wrap the rubber-splicing or self-amalgamating tape. Start as close to the equipment body as possible. Stretch and wind the tape around the connector housing, ensuring there are no gaps in the tape.



Figure 19: Wrapping the Connector with Rubber-splicing or Self-amalgamating Tape

2. Tightly wrap the connector and the cable. Overlap the tape, without gaps, all the way along the connector. Continue wrapping the tape 25 mm (1") onto the cable.



Figure 20: Wrapping the Cable with Rubber-splicing or Self-amalgamating Tape

3. For UV protection of the rubber splicing tape, wrap two layers of electrical tape on top of the rubber splicing tape.



Figure 21: Wrapping the Connector with Electrical Tape

4. Work mastic putty or duct sealing putty between the connector and the body of the radio or antenna. Ensure the putty fills any gaps not covered by the tape.



Figure 22: Sealing Gaps with Putty

5. Apply two layers of electrical tape over the rubber splicing tape for UV protection.

Figure 23 shows the base station connectors wrapped with splicing and electrical tape, before the application of mastic or duct sealing putty.



Figure 23: Base Station Connectors wrapped with Splicing and Electrical Tape



WARNING!

Assembly without waterproof sealing tape or removing the waterproof sealing tape from this device voids its warranty.

Section 4.6

Hazardous Location Installation

This equipment is suitable for use in Class 1, Division 2, Groups A, B, C, D hazardous locations only when installed using the Class 1, Division 2 installation kit (P/N MKIT0090).



WARNING!

EXPLOSION HAZARD

- *Substitution of components may impair suitability for Class I, Division 2*
- *Do not disconnect equipment unless power has been switched off or the area is known to be non-hazardous*
- *Use only Lambda DPP240-48-1 Power Supply in conjunction with the unit*

RISQUE D'EXPLOSION

- *La substitution de composants peut rendre ce matériel inacceptable pour les emplacements de Classe I, Division 2*
- *Avant de déconnecter l'équipement, couper le courant ou s'assurer que l'emplacement est désigné non dangereux*
- *Utilisez l'unité uniquement avec une batterie de la marque Lambda DPP240-48-1*

Contents of the Class 1, Division 2 Installation Kit:

- Lambda power supply unit (model DPP240-48-1)
- Y-Box Surge Suppression Unit
- DC cable for connection between the power supply unit (PSU) and the power-over-ethernet (PoE) injector

To install the equipment in a hazardous location, do the following:

1. Connect a DC cable between the PSU and PoE injector.




Figure 24: Connection Scheme

2. Connect a Category 5e cable between the PoE injector (Data+Power jack) and the pBST.
3. Connect a Category 5e cable between the Ethernet switch and the PoE injector (Data jack).
4. Connect the AC open-ended cable to the PSU.



Figure 25: Complete Class 1 Division 2 Installation Kit



CAUTION!

The power supply AC cord should be 3 wires, 18 AWG minimum, with a length of less than 4.5 m, and safety certified according to national rules.

5 Setup

The initial setup procedure consists of:

- Configuring the computer's network parameters and connecting to the WIN7200 Web interface
- Verifying IP connectivity

Section 5.1

Connecting to the WIN7200 Web Interface

This section describes how to configure the network parameters in Microsoft Windows so you can connect a computer to the WIN7200. For instructions on how to configure the network parameters for other operating systems, refer to your operating system documentation.

Before beginning, ensure that the base station is connected to the Power over Ethernet (PoE) power adaptor and that power is applied.

Follow these steps connect a computer to the WIN7200 Web interface:

Procedure: Connecting a computer to the base station

1. Ensure that the PoE adaptor is connected to the base station. Connect the computer's Ethernet port to the PoE adaptor's Ethernet port.
2. On the computer, click **Start** and select **Control Panel**.
3. In the **Control Panel**, select **Network and Internet Connections**.
4. Select **Network Connections** and then double-click **Local Area Connection**. The **Local Area Connections Properties** dialog appears with the **General** tab selected.




Figure 26: Microsoft Windows Local Area Connection Properties dialog box

5. In the **Items** list, select **Internet Protocol (TCP/IP)** and click the **Properties** button. The **Internet Protocol (TCP/IP) Properties** dialog appears.
6. Assign your computer the IP address 192.168.100.99 and the subnet 255.255.255.0.




Figure 27: Microsoft Windows Internet Protocol (TCP/IP) Properties dialog box

7. On the **Internet Protocol (TCP/IP) Properties** dialog, click **OK**. On the **Local Area Connection Properties** dialog, click **Close**.
8. Launch your web browser and type `https://192.168.100.100` in the address field.



NOTE

For information on browser versions and compatibility, refer to the release notes for your software version.

- The **Login** window appears. Enter your user name and password and click **Log In**. The WIN7200 web interface appears.

BS

STATUS
OFF

DOWNLINK
0.00 Mb/s

UPLINK
0.00 Mb/s

ALARMS
0

REGISTERED
0 MS

Admin **Subscribers** **Backbone** **Wireless** **Quick Start**

General
Current Status
Device Info
Installation Specifics
Security
Alarms and Traps
SW Upgrade
GPS
SNMP
Redundancy
Logout

Current Status

This page contains the current status of main parameters

Legend:
* requires service restart
** requires reboot

Current Frequency [kHz]	3555000
Current Bandwidth [MHz]	10MHz
Current Preamble Index	0
Current BS IP Address	192.168.10.10
GPS Time	12-Jan-2001 22:16:15.040
Uptime [sec]	286:16:12
Tx Status	Operational

Figure 28: WIN7200 Web Interface: General Status page

6 Troubleshooting

Section 6.1

No IP Connectivity

If there is no IP connectivity between the WIN7200 unit and the NMS, perform the following steps:

1. Connect the the computer and the WIN7200 Console connector (serial connection), located on the unit's bottom panel.
2. In the terminal, type **showIPAddr** and press **Enter**. The base station's IP address will be displayed.
3. Ping the WIN7200 unit address.
4. If connectivity is still not established, contact Siemens customer support.

Section 6.2

No Serial Connection

If there is no serial connection when using the serial cable, perform the following:

1. Verify IP connectivity using a ping to the WIN7200 unit IP address.
2. If there is no IP connectivity, verify the power connections.
3. If the power connections are okay, however, there is still no serial connection or IP connectivity, contact Siemens customer support.



List of Acronyms

Table: List of Acronyms

Acronym	Description
ASN	Access Service Network
BST	Base Station
CPE	Customer Premise Equipment
FTP	File Transfer Protocol
GW	Gateway
HTTP	Hypertext Transport Protocol
IDU	Indoor Units
IEEE	Institute of Electronic and Electrical Engineers
IP	Internet Protocol
LAN	Local Area Network
LOS	Line-of-Sight
NLOS	Non-Line-of-Sight
NMS	Network Management System
ODU	Outdoor Units
QoS	Quality of Service
RF	Radio Frequency
SLA	Service Level Agreements
SNMP	Simple Network Management Protocol
TCP	Transmission Control Protocol
WiMAX	Worldwide Interoperability for Microwave Access
RUGGEDCOM	RUGGEDCOM WiMAX Product Family
RUGGEDCOM NMS	RUGGEDCOM Network Management System

WIN7200 Specifications

Radio and Modem:

- Frequency:
 - WIN7225: 2483 to 2690 MHz
 - WIN7233: 3300 to 3400 MHz
 - WIN7235: 3400 to 3600 MHz
 - WIN7237: 3600 to 3720 MHz
 - WIN7249: 4900 to 5000 MHz
 - WIN7251: 4900 to 5200 MHz
 - WIN7258: 5725 to 5850 MHz
- IEEE 802.16-2005 (16e OFDMA)
- WiMAX Forum Wave 2 Profile
- Time Division Duplex (TDD)
- Channel Bandwidth (MHz) 3.5, 5, 7, 10
- Frequency Resolution 0.25 MHz
- Diversity Support 2x2, STC/MIMO-SM
- FEC Convolution Code and Turbo Code
- Transmit Power Control
- Output Power (average)
 - 2 X 27 dBm
 - 2 x 24 dBm — 4.9-5.0 GHz* (*consult the factory for availability)
- Modulation 512/1024 FFT points; QPSK, 16QAM, 64QAM

Radio Interfaces:

- Number of Antennas 2
- Antennas Connectors 2 × N-Type, 50 ohm, lightning protected
- Integrated or External Sector or Omni Antenna
- Built-in GPS included

Network Interfaces:

- 10/100BaseT Half / Full Duplex IEEE 802.3 CSMA/CD
- ASN GW Compatibility WiMAX Forum R6, Profile C

Configuration and Management:

- Web GUI: HTTPS
- Management SNMP
- SNMP Agent SNMP version 2 client/ SNMP v3

- Software Upgrade SFTP
- Remote Configuration SFTP

Mechanical:

- Dimensions [H × W × D] 228mm × 257mm × 112mm
- Weight <4kg

Power Interface:

- Power supply Input
 - 85-265 VAC
 - 10–60 VDC or 88–300VDC and
 - 85–264VAC (RP 100/110)
- Power Consumption 25 Watt max (average power)

Standards Compliance

Environmental:

- Operating Temperature: -40°C to +70°C
- Operating Humidity 5%-95% non condensing
- Weather protected: IP67
- IEC 61850-3 section 5.2, 5.3, 5.5
- IEC 870-2-2 section 3
- Designed to meet and exceed AREMA C&S Manual part 11.5.1 as applicable
- Hazardous Locations:
 - Class 1 Div 2 (UL 1604, CSA 22.2 No213- M1987)
 - ATEX Zone 2 (EN60079-0, EN60079-15)
- Corrosion: MIL-STD-810F 509.4 - salt fog

Safety:

- EN60950-22
- TUV 60950-1
- IEC 60950-1
- 1613 Section 5, 6.2
- IEC 60255-5 section 6.14

Radio:

- EN 302 544-2 -1
- EN302 326-1, EN302 326-2, EN302 326-3
- FCC CFR 47 Part 27
- FCC CFR 47 Part 90

EMC:

- FCC part 15, subpart B, class A
- ETSI EN 301 489-1 V1.8.1
- ETSI EN 301 489-4 V1.3.1

- 1613 section 6.3, 7, 8, 9 Class 1
- IEC 61850-3 section 5.7, 5.8
- EN55022



IDU to ODU Cable Specifications

Special 4×2×24 AWG FTP Cat. 5e Outdoor Double Jacket Data Cable UL (1581 VW 1)

Table: IDU to ODU Cable Description

Applications:	Outdoor installations, fixed or portable installations, digital distribution frames in transmission stations, outdoor installations in harsh environments.
General Construction:	Custom made cable designed specially for wireless systems, meeting the requirements of Cat. 5e per ANSI/TIA/EIA-568-B.2 and IEC 61156-5. The cable contains 4 twisted pairs, cabled, foil-tape shielded and jacketed with two special black UV resistant, flame retardant PVC compounds for direct outdoor use in harsh electrical environments. The diameter of the inner core complies with RJ45 connecting hardware allowing direct connection to equipment without patch cords.
Conductor Size:	0.52mm
Outer Jacket Material:	UV resistant FR-PVC
Outer Diameter:	7.9mm nominal
Weight:	68.0kg/km

Table: IDU to ODU Cable Design and Materials

Conductor Material:	Bare copper
Conductor Size:	24 AWG
Insulation Material:	Solid PO
Insulation O.D.:	1.07mm
Color Code:	Per TIA/EIA 568-B
Overall Foil Shield:	Yes
Overall Shield Material:	Aluminum/Polyester Foil
Overall Foil Design:	100% Coverage
Overall Drain-wire Material:	Tinned Copper
Overall Drain-wire Size:	24 AWG
Overall Drain-wire Construction:	Stranded
Inner Jacket Material:	UV resistant FR-PVC
Inner Jacket Diameter:	6.1mm
Total Number of Wires:	8

Table: IDU to ODU Cable Standards

Flammability Rating:	IEC60332, UL1581 VW-1
Standards:	IEC 61156, TIA/EIA-568

Table: IDU to ODU Cable Performance

Frequency Range:	1-100 MHz
Impedance:	100Ω
DC Resistance:	93Ω/km nominal
Max. DC Resistance	95Ω/km@20°C
Capacitance Unbalance:	1.6pF/m max.
Velocity of Propagation:	68% nominal
Propagation Delay Skew:	35 ns/100m max.
Dielectric Strength:	700 V/minute
Dielectric Strength to Shield:	700 V/minute
Min. Bend Radius:	70mm
Max. Operating Temperature:	+70°C
Min. Operating Temperature:	-40°C



Console Connector Specifications

**WARNING!**

The Console connector should be closed in normal conditions and is only intended for the use of an authorized technician.

The chassis has an RJ-45 maintenance female connector, used by a technician to connect a *console*.

The port is used by maintenance personnel to communicate with the processor when the normal management interfaces cannot be used. The console port is based on the RS-232 serial standard and supports a standard terminal connection.

The Console port enables the technician to configure and monitor the WIN7200 unit through a CLI (Command Line Interface) for low level debugging.

The following table describes the console connector pinout.

Table: Console Connector Pinout

Pin Number	Type
1	TX
2	RX
5	GND

The serial cable used to connect the WIN7200 Console port to the console is supplied by Siemens.

- Cable Type: Cat5
- Cable Connectors: DB9F; RJ45
- Cable Length: 2m



WIN7200 Base Station Mechanical Drawing




Figure 29: WIN7200 Base Station Mechanical Drawing

